


SOGEMAN BUGBUSTERS #MDSNAP

Easy to install companionway screens fix kit, if you do not have handrails or easy access point for straps attachments.


- Just slide the companionway screen webbings in the buckles.
- Fix each snap on your deck with supplied screws.
- Adjust and snap in place.
- Now have an easy way to install and remove your screen!

Kit de fixation facile à installer si vous n'avez pas accès aux mains courantes ou point de fixation pour les sangles.

- *Insérer les sangles des moustiquaires de descente dans les boucles.*
- *Visser les boutons sur le pont avec les visées fournies.*
- *Ajuster et fixer en place.*



Conception YM - Sogeman
• Danville • Qc • Canada
• 819-960-6731
• Email: info@sogeman.com
• Web: www.sogeman.com



FIX KIT WITH SNAPS FOR EASY INSTALLATION OF YOUR COMPANIONWAY SCREENS



KIT DE FIXATION POUR L'INSTALLATION FACILE DES MOUSTIQUAIRES DE DESCENTE

#MDSNAP

- 1- Slide the companionway screen top webbings in the buckles following the path in drawing.
- 2- Place both buckles at safe distance, not too close to the screen to prevent too much pull on the snap.
- 3- Drill a hole for each snap with a 3/32" bit.
- 4- Put a bit of silicone and screw the male snap on deck with supplied screws.
- 5- Adjust webbings and snap in place.

- 1- *Insérer les sangles de fixation du moustiquaire de descente dans les boucles, selon le dessin.*
- 2- *Placer les deux boucles à distance raisonnable pour empêcher que le moustiquaire les soulève et relache les boutons de fixation.*
- 3- *Percer les trous pour les deux visées de chaque côté du moustiquaire avec une mèche de 3/32".*
- 4- *Mettre un peu de silicone et visser les boutons sur le pont avec les visées fournies.*
- 5- *Ajuster les sangles et fixer en place.*